

USAGE AND CARE INSTRUCTIONS FOR YOUR BOSS AIR COMPRESSOR

BOSS Air Suspension's range of 12 and 24v Air Compressors are designed to withstand harsh Australian conditions and use the latest technology to deliver compressors that perform tirelessly for many years.

Take care of your BOSS Compressor

BOSS air compressors are built to last and they are oil free so require very little maintenance.

- The air filter is the lifeblood of the compressor. Your compressor needs access to clean fresh air to produce compressed air so at regular intervals, inspect your BOSS air compressors air filter mounted on the front of the unit. If its dusty, undo and clean it out with an air duster or similar. If the filter is damaged, BOSS have spare parts in stock so give them a call.
- Make sure the compressor is never run without an air cleaner attached or broken as dust and dirt will damage the piston ring and
 effect the performance of the unit and warranty.
- If the compressor fails to start, check all the electrical connections. If a circuit breaker has tripped or a fuse blown, test the electrical circuit and find the fault before resetting the breaker or replacing the fuse. If in doubt, call Boss, we are only a phone call away and we can talk you through it.
- If after years of use you find the compressor not pumping efficiently. If this occurs check the one-way valve (called a "check valve") on the end of the braided hose. If the inside of the valve is rusty or not working, replace it. The valve is designed to allow air to flow out from the compressor but block the return path. If the valve is not working, it will put pressure onto the compressor head and cause failure.
- If the compressor is still not pumping any volume it could be time for a rebuild. BOSS has rebuild kits available for all their compressors.

HELPFUL HINTS

Make sure there is plenty of air circulating around the compressor, it avoids overheating. The compressor is water resistant so care must be taken not to submerge in water. The compressor can be mounted vertical or horizontal as it contains no oil.

Your BOSS Warranty

BOSS Australasia Pty Ltd ('BOSS') warrants to the original purchaser that the product sold or distributed by BOSS (the Product) will be free from defects in materials and workmanship for the warranty period of 12 months commencing on the date of purchase from BOSS ('the Warranty').

BOSS, will rectify any defect in materials or workmanship appearing within the Warranty period by repairing or replacing the Product (at its option).

BOSS reserves the right to determine whether the Product contains any defects in materials or workmanship covered by the Warranty.

The benefits offered by this Warranty are in addition to your rights and remedies under the Australian Consumer Law. Our goods include all guarantees specified under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and you are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

How to make a warranty claim

A claim under the Warranty must be made within the Warranty period identified below, which commences on the date of purchase from BOSS. To make a Warranty claim, the Product must be returned to the BOSS together with proof of purchase unless otherwise agreed by BOSS.

Any costs incurred in making a Warranty claim or returning a Product to BOSS are to be borne by the person making the Warranty claim unless otherwise agreed by BOSS.

Exclusions

f

This Warranty does not cover any defect or injury caused by, or associated with improper installation or maintenance; unauthorised service, repair, modification or alteration; unsuitable physical or operating environment; electrical supply; acts of God; misuse, abuse or neglect; accidental damage, or other alterations or modifications which affect the reliability or performance of the product not attributable to a defect in materials or workmanship.